

RODI cycling

User Manual

Congratulations on purchasing your new RODI wheels!

This manual contains crucial information about the safe operation and maintenance of your wheelset and it is intended for aluminium bicycle wheels. Before your next adventure, we advise you to read and understand this manual's directions so that you experience more enjoyable and carefree rides. Third users also should be informed of the following provisions.

Please be advised that many bicycle maintenance and repair tasks require experience, tools and expertise. General mechanical knowledge may not be enough to maintain or repair your bike properly. When in doubt, contact your dealer.

SAFETY INFORMATION

Compliance with the following provisions is essential to avoid possible damages and ensure proper operating conditions.

- Ensure the wheels are secured safely. Riding a bicycle with an improperly installed wheel may allow it to move and disengage from the bicycle. It might cause damage to the article and risk the riders' safety. Also, not mounting the wheels properly on the bicycle frame might result in problems with the shifters and handling.
- Installation and maintenance of your bicycle components assume fundamental knowledge.
- Only use original spare parts.
- The components must be used exclusively for the purpose for which they are intended.
- Components must be compatible with all bicycle parts.
- The components must not be altered or modified.
- RODI wheels are not designed to be installed on any bicycle for two riders (tandem bicycles).
- Do not exceed the maximum rated pressure specified by the tire or rim manufacturers when filling tires.
- The maximum recommended spoke tension is 120 Kgf.
- If there is evidence of damage, the components should not be used.

RODI

www.blackjackwheels.com | info@blackjackwheels.com

Apartado 1, 3801-551, Eixo - Aveiro - Portugal | Ph.: +351 234 920 260* | Fax: +351 234 931 476

*PT National landline call costs

RODI wheels are solely designed for:

- Installing in standard or race Road and MTB bicycles.
- Using the types of terrain identified in the products' description and specifications. In case of any doubt, check out RODI Cycling's official website and our **Classification for Bicycle Usage** article.
- Installation of tires within the ETRTO standard.

MAINTENANCE AND CLEANING

RODI wheels are high-performance products. As such, they require careful maintenance.

- Clean with a soft sponge and a suitable cleaner. Do not use high-pressure or harsh cleaning equipment.
- Remove foreign matter (grit, metallic particles, dirt) after every ride.
- Check the spoke tension, concentricity and wheel wear (after a 10'hour use).
- Check the wheel for damages, such as fractures (before and after each round).
- Check the correct setting (before and after each round).
- Check the tire pressure (before each round).
- Verify the correct mounting of the wheel (before each round).



Note: This user manual is intended for aluminium wheelsets. These products do not contain any hazardous substances and are recyclable. When discarding this product, ensure it is recycled.

Warranty Conditions

RODI components are covered under warranty according to current legislation. Portuguese law is applied. That is why **we grant the statutory 3-year warranty for all our aluminium wheels**. Warranty and liability rights can only be considered valid with the sales receipt and if submitted by the first purchaser.

In case of a warranty request, you should contact your dealer. Failures recognized by **RODI** as covered by warranty will be repaired or replaced by your dealer.

RODI is responsible for damages proven to be the manufacturer's responsibility. The brand is not responsible for any damages, especially those related to indirect, immediate, and consequential damages. The following cases are excluded from the warranty:

- Normal wear and tear resulting from the use of the component.
- Incorrect assembly.
- Incorrect or non-existent maintenance.
- Faulty repair.
- Use of improper products.
- Component modification.
- Misuse.
- Neglected treatment.
- Rental or commercial use.
- Damage due to accidents.
- Damage in transportation and delivery.
- Change, make unrecognizable or remove the serial number.

Dear customer, whenever you need to activate the warranty or report any problems related to your wheels, contact us through our official website www.rodicycling.com or send an email to rodi@rodi.pt.

RODI

www.blackjackwheels.com | info@blackjackwheels.com

Apartado 1, 3801-551, Eixo - Aveiro - Portugal | Ph.: +351 234 920 260* | Fax: +351 234 931 476

*PT National landline call costs

RODI